


# WAKA WAKA POWER 5 MANUAL


## RECHARGEABLE POWERBANK

WAKA-WAKA.COM


### CONNECTORS



### CHARGING EXTERNAL DEVICE



### MICRO USB CHARGING LED INDICATORS & BATTERY STATUS




Use a micro-USB charging cable to charge the WakaWaka Power 5 via the grid. For best results use a WakaWaka micro-USB cable and the 2.1A USB-port at a WakaWaka World Charger. If your WakaWaka has been stored for a longer time it

can go into hibernation. Charge the WakaWaka via the grid (or connect it to the Solar Panel & Link) to wake it up and give it a powerboost. The battery status indicator lights turn off when the WakaWaka Power 5 is fully charged.

### WAKA WAKA SOLAR PANEL CHARGING LED INDICATORS

Solar indicator lights, if used with WakaWaka Solar Panel & Link.



USE THE WAKA WAKA POCKET LIGHT WITH YOUR WAKA WAKA POWER 5



## SPECIAL FEATURES



PATENTED INTIVATION  
SUNBOOST CHIP



SAFE BATTERY  
TECHNOLOGY



DEEP DISCHARGE  
PROTECTION FOR MAX  
BATTERY LIFETIME




2 YEARS  
WARRANTY

## SPECIFICATIONS

Battery	5,000 mAh LiPo
Average smartphone charge	2.5 x
Connectors	USB power in 2.1A   3 x USB out 2.1A
Weight	200 grams
Dimensions	122 x 80 x 18 mm
Color	Yellow

## CHARACTERISTICS & SPECIAL FEATURES

Fully charged in  
5 hours from the  
grid or 4-8 hours  
in the sun\*



\* Based on optimal sun conditions. Charge speed may vary.

## CAUTION



DO NOT SUBMERGE



NO FIRE



DON'T DROP



MAXIMUM AMBIENT  
TEMPERATURE: 80°C / 175 F

## FOLLOW US



## SUPPORT & CONTACT



For any questions, returns and/or support check out our FAQ page [waka-waka.com/faq/](http://waka-waka.com/faq/) or send us an email [support@waka-waka.com](mailto:support@waka-waka.com)

## WARRANTY

### 1. Limited warranty:

WakaWaka warrants to the original purchaser that this WakaWaka product will be free from defects in workmanship and material under normal consumer use during the applicable warranty period identified in Paragraph 2, below, subject to the exclusions set forth in Paragraph 4, below. This warranty statement sets forth WakaWaka's total and exclusive warranty obligation. We will not assume, nor authorize any person to assume for us, any other liability in connection with the sales of our products.

### 2. Warranty period:

The warranty period for the WakaWaka product is 2 years. The warranty period starts on the purchase date by the original purchaser. The sales receipt from

this purchase, or other reasonable documentary proof, is required in order to establish the start date of the warranty period.

### 3. Remedy:

WakaWaka will repair or replace (at WakaWaka's option and expense) any WakaWaka product that fails to operate during the applicable warranty period due to a defect in workmanship or material.

### 4. Exclusions:

WakaWaka's warranty does not apply to any product that is misused, abused, modified, damaged by accident, or used for anything other than normal consumer use as authorized in WakaWaka's then-current product literature.